


## ■ Network module for Profibus DP

FX3S  FX3G  FX3GC  FX3GE  FX3U  FX3UC  FX5U  FX5UC



### Profibus DP master modul

The Profibus DP master modules FX3U-64DP-M and FX5-DP-M enable you to integrate a MELSEC FX3U/FX3UC or FX5/FX5UC PLC system as a class 1 master of a Profibus DP network.

This interface module provides your base unit with an intelligent Profibus DP link for the implementation of decentralised control tasks.


A FX3U Profibus DP master provides comprehensive data and alarm processing to the Profibus DP V1 standard. The FX3U-64DP-M is easily set up with the GX Configurator-DP software. The FX5-DP-M can be configured within GX Works3 if the Profibus configuration tool is installed.

Specifications	FX3U-64DP-M	FX5-DP-M
Applicable for	Base units FX3U, FX3UC	Base units FX5U, FX5UC
Module type	Master station	
Transmission type	Bus network	
Transmission data	32 byte/slave (normal service mode) 244 byte/slave (extended service mode)	
Interface	Profibus DP (with 9 pole D-SUB connector)	
Max. number of master per configuration	Max. 1	
Repeaters	3	
Max. number of slaves	64	
Communications speed	Profibus standard	
Communications distance	m Max. 1200 (depends on communication speed)	
Communication cable	Profibus cable with 9-pin D-SUB connector	
Power supply	5 V DC 24 V DC	— Max. 155 mA (from base unit)
Related I/O points	8	150 mA (from base unit)
Weight	kg 0.2	
Dimensions (WxHxD)	mm 43x90x87	40x90x85.3
<b>Order information</b>	Art. no. 166085	409822
Accessories	Profibus connector up to 12 Mbaud: PROFICON-PLUS, art. no. 140008 or PROFICON-PLUS-PG, art. no. 140009	

Notes: The FX3U-64DP-M can be used in combination with a FX3U or FX3UC base unit only. To connect this module to a FX3UC base unit, an adapter FX2NC-CNV-IF or a power supply FX3UC-1PS-5V is required.

## ■ Network module for Profibus DP

FX3S  FX3G  FX3GC  FX3GE  FX3U  FX3UC  FX5U  FX5UC



### Profibus DP slave module

The FX3U-32DP Profibus DP slave module is available for FX3G, FX3GC, FX3GE, FX3U and FX3UC series main units and allows the attached FX main unit to function as a slave station on a Profibus DP-V1 network.

Profibus DP-V1 functionality supports extensive alarm processing and messaging on top of standard cyclic data exchange.

Specifications	FX3U-32DP
Module type	Slave station
Transmission type	Bus network
Transmission data	Max. 144 bytes
Interface	9-pin D-SUB for Profibus DP
Max. number of slave stations per configuration	8
Communication speed	5 V DC 24 V DC
Communication distance	Max. 12 Mbit/s Max. 1200 (depends on communication speed)
Communication cable	Profibus cable with 9-pin D-SUB connector
Related I/O points	8
Power supply	24 V DC/145 mA (from base unit)
Weight	kg 0.2
Dimensions (WxHxD)	mm 43x90x89
<b>Order information</b>	Art. no. 194214

Note: To connect a FX3U-32DP to a FX3UC/FX3GC base unit, an adapter FX2NC-CNV-IF or a power supply FX3UC-1PS-5V is required.